

LOOK AFTER IT

Salt, Sun & Sea

Salt water and sea-spray won't damage your beanbag. But prolonged immersion can harm the metal zip sliders and, over time, the fabric.

Always rinse off salt water to prevent accelerated deterioration.

Topping Up

Most polystyrene beans compress over time, so you may need to top up your beanbag now and then. See our filling instructions online, or visit the Coast showroom and we'll do it for you.

Repairs & Replacements

For any damage or deterioration covered by our exterior guarantee or manufacturer's warranty, we'll repair or replace the product free of charge.

In all other cases we're happy to assess the damage and quote for repair or replacement. Usually we'll ask you to return the product, **washed**, for inspection. Most repairs are quick and very reasonably priced – often free.

NZ DESIGNED + MADE

Everyday luxury, made for life.

Since 2003, Coast has made beanbags and outdoor furniture to be loved, lived on and looked after.

- 5 year Exterior Guarantee
- Lifetime Manufacturer's Guarantee
- Free shipping worldwide

coastnewzealand.com
coastnewzealand.com/pages/contact
[@coastnewzealand](https://www.instagram.com/coastnewzealand)

COAST

NEW ZEALAND

BEAN BAG

Care Guide

The better you treat it,
the longer it will last.

Sunbrella® fabric · Cleaning · Re-proofing

Outdoor beanbags & accessories

MEET YOUR FABRIC

Sunbrella®

A solution-dyed acrylic developed for exterior use. It's highly water repellent yet breathable, and its solution-dyed fibres strongly resist fading.

Sunbrella is engineered to last **two to ten times longer** than conventional fabrics, and its colouring process avoids harmful effluents and uses far less water and energy.

Everyday Care

Brushing off dirt before it embeds, and wiping up spills straight away, delays the need for deep cleaning.

- Keep beanbags free of debris such as fallen leaves – usually a brush, damp cloth or hose is all you need.
- Wipe up spills as they happen.
- After heavy or prolonged rain, let covers air dry.
- Covers can be removed for machine washing, then re-sprayed with 303 Fabric Guard.
- If unused for a while (e.g. over winter), store under cover.

STEP BY STEP

Light Cleaning

1. Brush off loose dirt.
2. Mix **60 ml mild soap** in **4 litres** of lukewarm water (under 38°C).
3. Clean with a sponge or soft-bristle brush.
4. Let the solution soak into the fabric.
5. Rinse thoroughly to remove all soap.
6. Air dry.

Spot Cleaning

1. Lightly mist the stain with the cleaning solution.
2. Work in gently with a sponge or very soft brush.
3. Rinse thoroughly.
4. Blot with a clean, soft towel or sponge, or wet-vacuum.
5. Repeat until the stain is gone.

Need help with a specific stain? Download the **Sunbrella® Stain Chart** from the Product Care page at coastnewzealand.com.

DEEP CLEAN

Stubborn Stains & Mildew

Sunbrella doesn't promote mildew, but mildew can grow on dirt left on the fabric.

1. Mix **225 ml bleach + 60 ml mild soap** per 4 litres of clean water.
2. Spray over the whole area and let it soak in.
3. Scrub with a soft brush, sponge or clean towel.
4. Rinse thoroughly. Air dry.

If staining is severe, bleach quantities may be increased.

Machine Washing

Remove covers and wash cold (under 38°C) with normal mild laundry soap plus 225 ml bleach. Air dry.

Re-proofing with 303

After each thorough clean, restore water repellency with **303 High Tech Fabric Guard™**: clean, air dry fully, then apply two *thin* coats in a ventilated area. Two light coats beat one heavy one.

DO NOT dry clean · tumble dry · or use a steamer or steam iron. Iron on the synthetic setting only, after testing a hidden spot. Protect nearby non-Sunbrella fabrics from bleach.